


# HOW TO CHECK YOUR HEAD HEIGHT

— Understanding the requirements your stairs will need to meet



## HEAD HEIGHT

There must be at least 2m of head height throughout the stairwell. Measure your head height plumb off the front of the stair nosing to check you have enough room.

BROWSE OUR LIBRARY

OF COMPLETED PROJECTS AND INSPIRATIONAL DESIGNS AT

— [STYLECRAFTSTAIRS.CO.NZ](http://STYLECRAFTSTAIRS.CO.NZ)

QUERIES? CALL US

TO SPEAK DIRECTLY WITH ONE OF OUR EXPERIENCED TEAM MEMBERS

☎ 0800 896 500